

Test report ID XXXXX

Customer Example Company

Assignment Measurlabs provided testing services for food contact material as requested by the customer.

Sample(s) Sampling was performed by the customer.

Description: plastic film

Date of reception (dd/mm/yyyy): -

Batch number or other sample identification: -

Results The results presented on the next page(s) relate to the tested sample(s) only.

Summary of the results

| Tests performed | Compliance |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|
| Overall migration testing – simulants A, B, and D2 (all foodstuffs) | Compliant ¹ |
| ¹ Commission Regulation (EU) 10/2011 on plastic materials and articles intended for contact with food, as amended (last update Regulation (EU) 2025/351 of 21 February 2025). | |

On XXXXX, issued by



Niko Markkinen
Testing Expert

+358 50 589 2106
niko.markkinen@measurlabs.com

Measurlabs

Teollisuuskatu 33
00510 Helsinki
Finland



Test results - overall migration

Test methods

Test conditions

Food contact surface area/
food simulant volume

Test methods according to EN 1186-1. Migration method: cell migration. Test performed by an ISO/IEC 17025 accredited external service provider.

Simulant A: 1 hour at 100 °C
Simulant B: 1 hour at 100 °C
Simulant D2: 1 hour at 100 °C

0.43 dm²/45 ml

| Test - simulant | Simulant | Unit | Result | Criteria | Compliance ¹ |
|---------------------------------|----------------|--------------------|-----------------------------|----------|-------------------------|
| Overall migration - simulant A | 10% ethanol | mg/dm ² | < 0.5 (< 0.5; < 0.5; < 0.5) | ≤ 10 | compliant |
| Overall migration - simulant B | 3% acetic acid | mg/dm ² | < 0.5 (< 0.5; < 0.5; < 0.5) | ≤ 10 | compliant |
| Overall migration - simulant D2 | Olive oil | mg/dm ² | < 0.5 (< 0.5; < 0.5; < 0.5) | ≤ 10 | compliant |

¹ Commission Regulation (EU) 10/2011 on plastic materials and articles intended for contact with food, as amended (last update Regulation (EU) 2025/351 of 21 February 2025).

End of the test report